

Style List

* Styles that have been added in Version 2 have a "*" symbol next to their name.

STYLE SELECT Button	No.	Style Name	Category	Tempo
[POP/ROCK]	001	StraightRock	ROCK	136
	002	SteadyRock	ROCK	110
	003	Rock	ROCK	158
	004	Crossover	ROCK	180
	005	LatinRock	ROCK	124
	006	HardRock	ROCK	123
	007	AmericanHR	ROCK	128
	008	ShuffleRock	ROCK	160
	009	NewWave	ROCK	122
	010	GramRock	ROCK	121
	011	ShuffleHR	ROCK	148
	012	WestCourst	ROCK	94
	013	SurfRock	ROCK	150
	014	Riverpool	ROCK	132
	015	Alternative1	ROCK	105
	016	Alternative2	ROCK	125
	017	PopRock	ROCK	123
	018	EuroPopRock	ROCK	120
	019	Acoustic	ROCK	92
	020	RockShuffle	ROCK	91
	021	AOR	8BEAT	95
	022	AorPop	8BEAT	68
	023	BritPop	8BEAT	85
	024	80sBritishPop	8BEAT	114
	025	PianoBallad	8BEAT	68
	026	PoppinBallade	8BEAT	80
	027	AorBallade	8BEAT	87
	028	HardRockBallade	8BEAT	68
	029	SmilePop	8BEAT	122
	030	OrganBallade	8BEAT	75
	031	GermanPop	8BEAT	180
	032	GuitarPop	POP	85
	033	RockPop	POP	94
	034	DiscoPop	POP	130
	035	68Pop	POP	64
	036	OrientalPop	POP	97
	037	Irish	POP	110
	038	ItalianPop	POP	110
	039	EasyPop	16BEAT	73
	040	16BeatPop	16BEAT	110
	041	SoulBallad	16BEAT	80
	042	PopBallad	16BEAT	69
	043	24BeatPop	16BEAT	85
	044	NightPop	16BEAT	76
	045	LatinPop	16BEAT	102
	046	LightPop	16BEAT	96
	047	FeelGood	16BEAT	103
	048	GroovyPop	16BEAT	103
	049	AcidJazz	16BEAT	95
	050	Motown	16BEAT	95
	051	Unplugged	16BEAT	87

STYLE SELECT Button	No.	Style Name	Category	Tempo
[POP/ROCK]	052	GuitarBallad	BALLAD	84
	053	EPBallad	BALLAD	62
	054	Ballad	BALLAD	66
	055	Lounge	BALLAD	90
	056	SmoothBallad	BALLAD	80
	[DANCE]	057	Techno1	DANCE
058		Techno2	DANCE	136
059		Techno3	DANCE	140
060		House1	DANCE	125
061		House2	DANCE	128
062		SoulPop	DANCE	118
063		AcidDance	DANCE	102
064		Disco	DANCE	124
065		Rap	DANCE	97
066		Reggaeton	DANCE	88
067		CoolRap	DANCE	98
068		Hiphop1	DANCE	80
069		Hiphop2	DANCE	160
070		Hiphop3	DANCE	95
071		R&B1	DANCE	113
072		R&B2	DANCE	84
073		ReggaePop	DANCE	86
074		R&B	DANCE	87
075		Electronic	DANCE	130
076		R&BDance	DANCE	90
077		DancePop	DANCE	118
078		Breakbeat	DANCE	126
[JAZZ/LATIN]	079	JazzBallad1	JAZZ	70
	080	BigBand1	JAZZ	118
	081	JazzClub	JAZZ	122
	082	BigBandBallad	JAZZ	76
	083	JazzWaltz	JAZZ	140
	084	FastSwing	JAZZ	220
	085	JazzBallad2	JAZZ	60
	086	SmoothJazz	JAZZ	98
	087	BigBand2	JAZZ	82
	088	FolkJazz	JAZZ	88
	089	SoulJazz	JAZZ	120
	090	LuvBossa	LATIN	130
	091	MidBossa	LATIN	150
	092	UpBossa	LATIN	170
	093	UpSamba	LATIN	100
	094	BossaPop	LATIN	98
	095	Salsa	LATIN	182
	096	Guarach	LATIN	110
	097	Merengue	LATIN	150
	098	Bachata	LATIN	120
	099	Jogetmly	LATIN	116
	100	TropicalPop	LATIN	116
	101	Caribbean	LATIN	116

Style List

STYLE SELECT Button	No.	Style Name	Category	Tempo
[TRADITIONAL]	102	Blues	TRADITIONAL	97
	103	70sR&B	TRADITIONAL	102
	104	RocknRollLullaby	TRADITIONAL	75
	105	FunkSoul	TRADITIONAL	104
	106	Reggae	TRADITIONAL	95
	107	Country	TRADITIONAL	240
	108	CountryPop	TRADITIONAL	138
	109	Cajun	TRADITIONAL	162
	110	Old6_8	TRADITIONAL	128
	111	OldiePop	TRADITIONAL	114
	112	Oldie	TRADITIONAL	186
	113	Gospel	TRADITIONAL	108
	114	Schlager	TRADITIONAL	120
	115	March	TRADITIONAL	122
	116	Polka	TRADITIONAL	132
	117	PolkaPop	TRADITIONAL	140
	118	Filmscore	TRADITIONAL	64
	119	70sDisco	BALLROOM	104
	120	BigSamba	BALLROOM	126
	121	Rockabilly	BALLROOM	166
	122	Boogie	BALLROOM	126
	123	Twist	BALLROOM	142
	124	WienerWaltz	BALLROOM	160
	125	EnglishWaltz	BALLROOM	104
	126	Tango	BALLROOM	125
	127	Musette	BALLROOM	200
	128	Mambo	BALLROOM	186
	129	Rhumba	BALLROOM	110
	130	Shuffle	BALLROOM	140
	[WORLD]	131	ChineseBlue	WORLD(CHINA)
132		ChineseJazzPop	WORLD(CHINA)	103
133		ChineseGameFunk	WORLD(CHINA)	95
134		ChinesePop1	WORLD(CHINA)	118
135		ChineseNewPop	WORLD(CHINA)	120
136		ChinesePop2	WORLD(CHINA)	115
137		ChineseR&BPop	WORLD(CHINA)	122
138		ChineseHipHop	WORLD(CHINA)	116
139		ChineseR&B	WORLD(CHINA)	128
140		ChinesePopDay	WORLD(CHINA)	120
141		ChineseFunkZ	WORLD(CHINA)	120
142		ChineseFunkPop	WORLD(CHINA)	80
143		ChineseRock	WORLD(CHINA)	120
144		ChineseLove	WORLD(CHINA)	65
145		ChineseBossa	WORLD(CHINA)	145
146		ChineseTechno	WORLD(CHINA)	145
147		ChineseTeenFunk	WORLD(CHINA)	90
148		ChineseFunkZ2	WORLD(CHINA)	120
149		ChineseSummer	WORLD(CHINA)	123
150		2RTechno	WORLD(CHINA)	140
151		MiaoJazz	WORLD(CHINA)	122
152		Mongol	WORLD(CHINA)	120

STYLE SELECT Button	No.	Style Name	Category	Tempo
[WORLD]	153	MongoTechno	WORLD(CHINA)	120
	154	Tanbo	WORLD(CHINA)	120
	155	TanboTechno	WORLD(CHINA)	120
	156	XinjiangPop	WORLD(CHINA)	120
	157	XinjiangRock	WORLD(CHINA)	147
	158	XinjiangTrad	WORLD(CHINA)	168
	159	XinjiangVocal	WORLD(CHINA)	100
	160	XinjiangHipHop	WORLD(CHINA)	80
	161	XinjiangLyric	WORLD(CHINA)	90
	162	Yunnan2_4Slow	WORLD(CHINA)	60
	163	Yunnan2_4	WORLD(CHINA)	90
	164	Yunnan2_4Fast	WORLD(CHINA)	100
	165	Yunnan3_4Slow	WORLD(CHINA)	80
	166	Yunnan3_4	WORLD(CHINA)	130
	167	Yunnan4_4Slow	WORLD(CHINA)	60
	168	Yunnan4_4	WORLD(CHINA)	90
	169	Yunnan6_8	WORLD(CHINA)	80
	170	Yangge	WORLD(CHINA)	122
	171	ChinesePop3 ★	WORLD(CHINA)	75
	172	ChinaTime ★	WORLD(CHINA)	70
	173	Kungfu ★	WORLD(CHINA)	89